

CROSSBREEZE





When the bottom pull rod is locked in the lowest position, there should be no gap between it and the base surface.

If you need to retract the screen upwards from this lowest locked position, gently tug the pull strip on the screen downwards and then release it. The screen will then retract upwards.

